



Floor Graphic Application Instructions

Jay-Line's Floor Graphics are designed to be applied to smooth surfaces including waxed and non-waxed commercial PVC tile, certain ceramic tile and sealed concrete.

Floor Condition:

Floor surface must be clean prior to application of graphics. Traditional floor cleaning methods can be used to prepare the surface. Ensure floor surface is dry prior to application of graphics

Application Method:

- 1. Peel the backing paper (release liner) 1" down from the top. Fold and crease the backing paper.
- 2. Align and apply the graphic starting at the top using firm strokes with a plastic squeegee, stiff cardboard or a soft cloth. Continue removing the backing paper and smooth out the squeegee. Re- squeegee the edges of the graphic using firm strokes to ensure edge adhesion.

Routine Maintenance:

- 1. Do not clean or wax graphics for at least 24 hours after application.
- 2. When selecting a floor wax, ensure it meets or exceeds ASTM D 2047 standards for appropriate static coefficient of friction (.5 min).
- 3. Avoid damaging graphics by heavy equipment traffic (fork trucks, pallets, or other heavy equipment).

CAUTION: To avoid risk of injury, immediately remove graphics if any edge of the graphic lifts, and replace with a new graphic.

Removal Instructions:

- 1. Lift one edge of the graphic and pull, using short, quick strokes.
- 2. Pull at an angle less than 45 degrees for best results.

Because all floors are different, the effect of the product will differ. No refunds will be given based on this. No exceptions. If you are thinking about purchasing this, please call us for a sample to test on your floor.